



INSTRUCTIONS FOR DEVON I CABINET

Dear **AFINA** Customer:

We appreciate your purchase of our **AFINA** bath Cabinet, and would like to provide you with the following helpful hints:

- For protection in shipping, the **GLASS SHELVES** and **SHELF PINS** are in a separate flat box inside the main box. It is clearly identified by a label marked "**GLASS SHELVES.**" Please look carefully and remove before discarding the box.
- It is important to make sure the cabinet body is level and plumb upon installation. Use a leveling instrument to insure accuracy, or the door may not close and/or secure itself properly.
- When **RECESSING** the cabinet, make the cutout in the wall 24" x 31 ¼". Use any of the pre-drilled holes on the side cabinet interior. Screws are **not** supplied, as we do not know the type of material you are going into (i.e., wood studs, metal studs). Make sure the cabinet is level and plumb before securing into framing studs.
- When **SURFACE MOUNTING** – mount the cabinet flush to the wall by putting a screw through the back panel and into the wall in each corner (top left and right; bottom left and right). Try to secure into a beam. If you cannot, use a wall anchor (not supplied).
- When cleaning your new **AFINA** cabinet, we recommend a mild cleanser, applied first to a rag or paper towel. **Do not** spray directly on to the mirror or frame.

We are confident your **AFINA** cabinet will reflect the quality and prestige you wish to convey in your home or business environment.

Thank you for purchasing **AFINA** products.